

3-1. Advanced touch controller [AT-50A]



- AT-50A features a 5 inch color LCD touch panel. The settings for air conditioning units can be changed by touching the corresponding icons on the display. On the panel of AT-50A are 3 buttons; ON/OFF, F1 and F2 enabling simple and quick operation.
- One AT-50A can control up to 50 groups/units of air conditioners.

Item	Description	Operations	Display
External input (Emergency stop input, etc.)	The following input with level signals or pulse signals are available. Level signal: "Emergency stop input" or "Collective ON/OFF" Pulse signal: "Collective ON/OFF" or "Local remote controller prohibit/permit" One input can be selected from those above. * An external input/output adapter (PAC-YT41HAA (sold separately)) is required. Relays and DC power supply or other devices must be prepared at the site.	⊙	⊙
External output (Error output, operation output)	"ON/OFF" and "error/normal" are output with the level signal. * An external input/output adapter (PAC-YT41HAA (sold separately)) is required. Relays and DC power supply or other devices must be prepared at the site.	⊙	⊙
Checking the Gas Amount	Use this function to check for refrigerant leak from the outdoor unit. * When this function is used, the gas amount checking function of the outdoor unit cannot be used. This function is for CITY MULTI R2 and Y(PUMY is excluded.) series only.	□	□
Main system controller /Sub system controller	AT-50A can be set to Sub System controller. When connecting multiple system controllers, designate the system controller with many functions as the "Main", and set the system controllers with few functions as the "Sub".	✓	—
Function Buttons (F1 Button, F2 Button)	The F1 button and the F2 button can be set as a run button of the following collective operation. (Setback/Schedule/Operation Mode/Temperature Correction/Remote Controller Prohibition)	⊙	⊙

■ Functions

□:Each unit ○:Each group ●:Each block ✓:Available
△:Each floor ⊙:Group or collective ✕:Not available

Item	Description	Operations	Display
ON/OFF	ON and OFF operation for the air conditioner units. Even when only a single indoor unit connected to the group remote controller will operate and collective ON/OFF lamp will light up.	⊙	⊙
Operation mode switching	Switches between Cool / Dry / Auto / Fan / Heat Operation modes vary depending on the air conditioner unit. Auto mode is for CITY MULTI R2 and WR2 series only.	⊙	⊙
Temperature setting	The temperature can be set within the following range. Cool/Dry : 19°C - 30°C / 67°F - 87°F Heat : 17°C - 28°C / 63°F - 83°F Auto : 19°C - 28°C / 67°F - 83°F Setback : [Upper limit] 19°C-30°C [19°C-30°C] / 67°F-87°F [67°F-87°F] [Lower limit] 12°C-28°C [17°C-28°C] / 53°F-83°F [63°F-83°F] * [] in case of using Mr.SLIM units. * Set temperature range varies depending on the model.	⊙	⊙
Fan speed setting	Models with 5 air flow speed settings: Hi/Mid-2/Mid-1/Low, Auto Models with 4 air flow speed settings: Hi/Mid-2/Mid-1/Low Models with 3 air flow speed settings: Hi/Mid/Low Models with 2 air flow speed settings: Hi/Low * Fan speed setting (including Auto) varies depending on the model.	⊙	⊙
Air flow direction setting	Air flow direction angles 4-angle or 5-angle, Swing, Auto Louver ON/OFF * Air flow direction settings vary depending on the model.	⊙	⊙
Permit / Prohibit	The ON/OFF, operation mode, setting temperature and filter sign reset operations using the local remote controllers can be prohibited. Only ON/OFF and filter reset can be prohibited for the LOSSNAY group.	⊙	⊙
Operation lock	The operation lock can be set to the input operation of AT-50A. Each button can be set. (Function Button 1, Function Button2, Collective ON/OFF, Touch Panel) Each function can be set. (Operation mode, Setting temperature, Fan speed, Menu button) The password for the lock release can be set.	⊙	⊙
Error display	When an error is currently occurring on an air conditioner unit, the afflicted unit and the error code are displayed. * When an error occurs, the "ON/OFF" LED flashes. The operation monitor screen show abnormal icon over the unit. The error monitor screen shows the abnormal unit address and error code. The error log monitor screen shows the time and date, the abnormal unit address, error code and source of detection.	✕	□ ⊙
Schedule operation	Weekly schedule setting up to 12 pattern is available. In one pattern, up to 16 setting of "ON/OFF", "Operation mode", "Set Temperature", "Fan speed", "Air flow direction" and "Permit / Prohibit local operation" can be scheduled. Two types of weekly schedule(Summer/Winter) can be set. Today's schedule setting up to 5 pattern is available. * Time setting unit: 5 minute /unit	○	○
Night setback setting	This function helps keep the indoor temperature in the temperature range while the units are stopped and during the time this function is effective.	⊙	⊙
Ventilation (independent)	Switches the mode "Bypass/Heat recovery/Auto" for LOSSNAY groups.	⊙	⊙
Ventilation (interlocked)	The LOSSNAY will run in interlock with the operation of indoor unit. The mode cannot be changed. The LED will turn ON during operation after interlocking.	⊙	⊙
Temperature-set limitation	Batch-setting to temperature range limit at cooling, heating, and auto mode. This function cannot be used with the MA remote controller. (Depends on the indoor unit model.)	⊙	⊙
Specific mode operation prohibit (Cooling prohibit, heating prohibit, cooling/heating prohibit)	When set as the main controller, operation of the following modes with the local remote controllers can be prohibited. When cooling is prohibited: Cooling, dry, automatic can not be chosen. When heating is prohibited: Heating, automatic can not be chosen. When cooling/heating is prohibited: Cooling, dry, heating, automatic can not be chosen.	⊙	⊙
System changeover	Operation mode can be switched to an optimal mode depending on indoor temperature setting and target temperature of each group or a representative indoor unit. * When this function is used, the system changeover function of the outdoor unit cannot be used.	●	—

■ External dimension

